

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.
ACER	Aspire 1200, 1300	Green(19V)	D	ACER	TI Extensa 395 Series, 395T	Green(19V)	C	ACER	TravelMate 360 Series	Green(19V)	D	APPLE	iBook G3	Orange(24V)	G	COMPAQ	Armada 4120	Red(18V)	D	COMPAQ	Presario 1080	Green(19V)	C
ACER	AcerNote 300 Series	Green(19V)	D	ACER	TI Extensa 500 Series, 500DX	Green(19V)	D	ACER	TravelMate 505 Series, 505DX	Green(19V)	E	APPLE	Power Book 1400 Series	Orange(24V)	G	COMPAQ	Armada 4130	Red(18V)	D	COMPAQ	Presario 1200	Green(19V)	C
ACER	AcerNote 350 Series, 350C/P/PC	Green(19V)	D	ACER	TI Extensa 501 Series, 501DX/T	Green(19V)	D	ACER	TravelMate 506 Series, 506DX/T	Green(19V)	D	APPLE	Power Book 3400 Series	Orange(24V)	G	COMPAQ	Armada 4131	Red(18V)	D	COMPAQ	Presario 1210	Green(19V)	C
ACER	AcerNote 352 Series	Green(19V)	D	ACER	TI Extensa 502 Series, 502DX/T	Green(19V)	D	ACER	TravelMate 507 Series, 507DX/T	Green(19V)	D	APPLE	Power Book G3	Orange(24V)	G	COMPAQ	Armada 4220	Red(18V)	D	COMPAQ	Presario 1215	Green(19V)	C
ACER	AcerNote 355 Series	Green(19V)	D	ACER	TI Extensa 503 Series, 503T	Green(19V)	D	ACER	TravelMate 508 Series, 508T	Green(19V)	D	ASUS	A1000 Series	Green(19V)	E	COMPAQ	Armada E500 Series	Red(18V)	E	COMPAQ	Presario 1220	Green(19V)	C
ACER	AcerNote 356 Series	Green(19V)	D	ACER	TI Extensa 505 Series, 505DX	Green(19V)	D	ACER	TravelMate 510 Series	Green(19V)	D	ASUS	ArtBook L7336	Green(19V)	E	COMPAQ	Armada E700 Series	Red(18V)	E	COMPAQ	Presario 1232	Green(19V)	C
ACER	AcerNote 358 Series	Green(19V)	D	ACER	TI Extensa 550 Series	Green(19V)	C	ACER	TravelMate 512 Series, 512DK/T/TE/T-64	Green(19V)	D	ASUS	B1000 Series	Green(19V)	E	COMPAQ	Armada M300 Series	Red(18V)	E	COMPAQ	Presario 1235	Green(19V)	C
ACER	AcerNote 361 Series	Green(19V)	D	ACER	TI Extensa 600 Series, 600CD/CDT	Green(19V)	C	ACER	TravelMate 513 Series, 513DX/T	Green(19V)	D	ASUS	F7400	Green(19V)	E	COMPAQ	Armada M700 Series	Red(18V)	E	COMPAQ	Presario 1236	Green(19V)	C
ACER	AcerNote 370 Series	Green(19V)	D	ACER	TI Extensa 900 Series	Green(19V)	C	ACER	TravelMate 514 Series, 514T/TVX	Green(19V)	D	ASUS	L1000B Series	Green(19V)	E	COMPAQ	Armada V300 Series	Red(18V)	E	COMPAQ	Presario 1237	Green(19V)	C
ACER	LifeNote 373	Green(19V)	D	ACER	TravelMate 200 Series, 200DX/T	Green(19V)	E	ACER	TravelMate 515 Series, 515TE	Green(19V)	D	ASUS	L2000B Series	Green(19V)	E	COMPAQ	Armada 3500	Red(18V)	E	COMPAQ	Presario 1240	Green(19V)	C
ACER	Light 350 Series, 350C/P/PC	Green(19V)	D	ACER	TravelMate 201 Series, 201T	Green(19V)	D	ACER	TravelMate 517 Series, 517TE	Green(19V)	D	ASUS	L2000D Series	Green(19V)	E	COMPAQ	Evo N115	Green(19V)	C	COMPAQ	Presario 1244	Green(19V)	C
ACER	Light 356 Series	Green(19V)	D	ACER	TravelMate 202 Series, 202T	Green(19V)	D	ACER	TravelMate 520 Series, 520T	Green(19V)	E	ASUS	L2000E Series	Green(19V)	E	COMPAQ	Evo N160	Green(19V)	C	COMPAQ	Presario 1245	Green(19V)	C
ACER	Light 358 Series	Green(19V)	D	ACER	TravelMate 210 Series, 210T/TVF	Green(19V)	D	ACER	TravelMate 521 Series, 521TE/TEV/TVX	Green(19V)	D	ASUS	L3000C Series	Green(19V)	E	COMPAQ	Evo N180	Green(19V)	C	COMPAQ	Presario 1247	Green(19V)	C
ACER	Light 370 Series	Green(19V)	D	ACER	TravelMate 212 Series, 212T/TVX	Green(19V)	D	ACER	TravelMate 524 Series, 524TE/TVX	Green(19V)	D	ASUS	L3000S Series	Green(19V)	E	COMPAQ	Evo N200	Red(18V)	E	COMPAQ	Presario 1250	Green(19V)	C
ACER	Light 371 Series	Green(19V)	D	ACER	TravelMate 220 Series	Green(19V)	D	ACER	TravelMate 525 Series, 525TX/TVX	Green(19V)	D	ASUS	L7233	Green(19V)	E	COMPAQ	Evo N400c	Red(18V)	E	COMPAQ	Presario 1255	Green(19V)	C
ACER	Light 372 Series,	Green(19V)	D	ACER	TravelMate 270 Series	Green(19V)	D	ACER	TravelMate 600 Series	Green(19V)	E	ASUS	L7300	Green(19V)	E	COMPAQ	Evo N600c	Red(18V)	E	COMPAQ	Presario 1260	Green(19V)	C
ACER	Light 373 Series	Green(19V)	D	ACER	TravelMate 310 Series, 310T	Blue(16V)	D	ACER	TravelMate 602 Series, 602TER	Green(19V)	D	ASUS	L8400	Green(19V)	E	COMPAQ	LTE 5000	Red(18V)	D	COMPAQ	Presario 1266	Green(19V)	C
ACER	Light 374 Series	Green(19V)	D	ACER	TravelMate 311 Series, 311T	Blue(16V)	D	ACER	TravelMate 603 Series, 603TER	Green(19V)	D	ASUS	M1000 Series	Green(19V)	E	COMPAQ	LTE 5150	Red(18V)	D	COMPAQ	Presario 1267	Green(19V)	C
ACER	Light 380 Series	Green(19V)	D	ACER	TravelMate 312 Series, 312T	Blue(16V)	D	ACER	TravelMate 630 Series	Green(19V)	D	ASUS	M2000 Series	Green(19V)	E	COMPAQ	LTE 5200	Red(18V)	D	COMPAQ	Presario 1272	Green(19V)	C
ACER	Light 382 Series	Green(19V)	D	ACER	TravelMate 313 Series, 313T	Blue(16V)	D	ACER	TravelMate 720 Series, 720TX	Green(19V)	D	ASUS	M2 Series, M2400	Green(19V)	E	COMPAQ	LTE 5250	Red(18V)	D	COMPAQ	Presario 1273	Green(19V)	C
ACER	TI Extensa 350 Series	Green(19V)	C	ACER	TravelMate 314 Series, 314T	Blue(16V)	D	ACER	TravelMate 721 Series, 721TX	Green(19V)	D	ASUS	MP 8xxx Series	Green(19V)	E	COMPAQ	LTE 5300	Red(18V)	D	COMPAQ	Presario 1274	Green(19V)	C
ACER	TI Extensa 355 Series	Green(19V)	C	ACER	TravelMate 320T	Blue(16V)	C	ACER	TravelMate 722 Series, 722ITX/ITXV/TVX	Green(19V)	D	ASUS	S1000 Series	Green(19V)	E	COMPAQ	LTE 5380	Red(18V)	D	COMPAQ	Presario 1275	Green(19V)	C
ACER	TI Extensa 360 Series	Green(19V)	C	ACER	TravelMate 330 Series, 330T	Green(19V)	D	ACER	TravelMate 723 Series, 723TX/TVX	Green(19V)	D	ASUS	T4700CS	Green(19V)	E	COMPAQ	LTE 5400	Red(18V)	D	COMPAQ	Presario 1277	Green(19V)	C
ACER	TI Extensa 365 Series	Green(19V)	C	ACER	TravelMate 332 Series, 332T	Green(19V)	D	ACER	TravelMate 730 Series	Green(19V)	E	ASUS	T7200	Green(19V)	E	COMPAQ	LTE 5480	Red(18V)	D	COMPAQ	Presario 1278	Green(19V)	C
ACER	TI Extensa 366 Series, 366D	Green(19V)	C	ACER	TravelMate 333 Series, 333T	Green(19V)	D	ACER	TravelMate 732 Series, 732TVX	Green(19V)	D	ASUS	T9000 Series	Green(19V)	E	COMPAQ	LTE 6000	Red(18V)	D	COMPAQ	Presario 1279	Green(19V)	C
ACER	TI Extensa 367 Series, 367D/T	Green(19V)	C	ACER	TravelMate 340 Series, 340T	Green(19V)	E	ACER	TravelMate 734 Series, 734TL	Green(19V)	D	COMPAQ	Armada 100	Red(18V)	D	COMPAQ	Presario 1010	Green(19V)	C	COMPAQ	Presario 1450	Green(19V)	C
ACER	TI Extensa 368 Series, 368D	Green(19V)	C	ACER	TravelMate 341 Series, 341TV	Green(19V)	D	ACER	TravelMate 735 Series, 735TLV	Green(19V)	D	COMPAQ	Armada 110	Red(18V)	E	COMPAQ	Presario 1020	Green(19V)	C	COMPAQ	Presario 1600i	Green(19V)	C
ACER	TI Extensa 390 Series	Green(19V)	C	ACER	TravelMate 342 Series, 342T	Green(19V)	D	ACER	TravelMate 736 Series, 736TL/TLV	Green(19V)	D	COMPAQ	Armada 1100	Red(18V)	D	COMPAQ	Presario 1030	Green(19V)	C	COMPAQ	Presario 1600s Series	Green(19V)	C
ACER	TI Extensa 391 Series, 391C/T	Green(19V)	C	ACER	TravelMate 343 Series, 343TV	Green(19V)	D	ACER	TravelMate 737 Series, 737TLV	Green(19V)	D	COMPAQ	Armada 1120	Red(18V)	D	COMPAQ	Presario 1060	Green(19V)	C	COMPAQ	Presario 1610	Green(19V)	C
ACER	TI Extensa 392 Series, 392C/T	Green(19V)	C	ACER	TravelMate 345T	Green(19V)	E	ACER	TravelMate 738 Series, 738TLV	Green(19V)	D	COMPAQ	Armada 1125	Red(18V)	D	COMPAQ	Presario 1065	Green(19V)	C	COMPAQ	Presario 1611	Green(19V)	C
ACER	TI Extensa 393 Series, 393C	Green(19V)	C	ACER	TravelMate 350 Series	Green(19V)	E	ACER	TravelMate 739 Series, 739TLV	Green(19V)	D	COMPAQ	Armada 1130	Red(18V)	D	COMPAQ	Presario 1070	Green(19V)	C	COMPAQ	Presario 1621	Green(19V)	C
ACER	TI Extensa 394 Series, 394T	Green(19V)	C	ACER	TravelMate 351 Series, 351TEV	Green(19V)	D	AMI	TF6720, TF6760, FT8850	Green(19V)	C	COMPAQ	Armada 4100	Red(18V)	D	COMPAQ	Presario 1075	Green(19V)	C	COMPAQ	Presario 1622	Green(19V)	C

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.
COMPAQ	Presario 1625	Green(19V)	C	DELL	Inspiron 3800	Red(18V)	F	DUAL	ERA1000, VDA 9950	Green(19V)	C	FUJITSU	E Series E351	Blue(16V)	A	FUJITSU	Lifebook 756Dx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 4101	Green(19V)	C
COMPAQ	Presario 1626	Green(19V)	C	DELL	Inspiron 4000	Red(18V)	F	E-Machine	E Slate Series, 450K	Green(19V)	C	FUJITSU	E Series E360	Blue(16V)	A	FUJITSU	Lifebook 765Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 4103	Green(19V)	C
COMPAQ	Presario 1645	Green(19V)	C	DELL	Inspiron 5000	Red(18V)	F	EPSON	Action Note 800, 866C, 880C/CX	Green(19V)	C	FUJITSU	E Series E362	Blue(16V)	A	FUJITSU	Lifebook 770Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 4105	Green(19V)	C
COMPAQ	Presario 1655	Green(19V)	C	DELL	Inspiron 5000e	Red(18V)	F	EPSON	Action Note 890, 890C, 895C	Green(19V)	C	FUJITSU	E Series E370	Blue(16V)	A	FUJITSU	Lifebook 790Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 4150 Series	Green(19V)	C
COMPAQ	Presario 1670	Green(19V)	C	DELL	Inspiron 7000	Green(19V)	C	EPSON	Action Note 900, 910C	Green(19V)	C	FUJITSU	E Series E380	Blue(16V)	A	FUJITSU	Lifebook 900 Series	Blue(16V)	A	HEWLETT PACKARD	OmniBook 500	Green(19V)	C
COMPAQ	Presario 1680	Green(19V)	C	DELL	Inspiron 7500	Red(18V)	F	EPSON	Endeavor TK-300 Series	Blue(16V)	C	FUJITSU	E Series E6540	Blue(16V)	A	FUJITSU	Lifebook 985Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 6000 Series	Green(19V)	C
COMPAQ	Presario 1681	Green(19V)	C	DELL	Inspiron 8000	Red(18V)	F	Featron	FT8850, FT9900 Series	Green(19V)	C	FUJITSU	E Series E6556	Blue(16V)	A	FUJITSU	Lifebook 990Tx2	Blue(16V)	A	HEWLETT PACKARD	OmniBook 7100 Series	Green(19V)	C
COMPAQ	Presario 1682	Green(19V)	C	DELL	Latitude C Series	Red(18V)	F	FUJITSU	A Series A4170	Blue(16V)	A	FUJITSU	E Series E6570	Blue(16V)	A	FUJITSU	S Series S4510	Blue(16V)	A	HEWLETT PACKARD	OmniBook 7103	Green(19V)	C
COMPAQ	Presario 1685	Green(19V)	C	DELL	Latitude C500	Red(18V)	F	FUJITSU	B Series B112	Blue(16V)	A	FUJITSU	L Series L440	Blue(16V)	A	FUJITSU	S Series S452	Blue(16V)	A	HEWLETT PACKARD	OmniBook 7150 Series	Green(19V)	C
COMPAQ	Presario 1687	Green(19V)	C	DELL	Latitude C600	Red(18V)	F	FUJITSU	B Series B142	Blue(16V)	A	FUJITSU	L Series L470	Blue(16V)	A	FUJITSU	S Series S-4542	Blue(16V)	A	HEWLETT PACKARD	OmniBook 900 Series	Green(19V)	C
COMPAQ	Presario 1688	Green(19V)	C	DELL	Latitude C800	Red(18V)	F	FUJITSU	B Series B2130	Blue(16V)	A	FUJITSU	Lifebook L400 Series	Blue(16V)	A	GATEWAY	Solo 1100 Series	Green(19V)	D	HEWLETT PACKARD	OmniBook XE Series	Green(19V)	C
COMPAQ	Presario 1690	Green(19V)	C	DELL	Latitude CP Series	Red(18V)	F	FUJITSU	B Series B2131	Blue(16V)	A	FUJITSU	Lifebook 270Dx	Blue(16V)	A	GATEWAY	Solo 2100 Series	Green(19V)	D	HEWLETT PACKARD	OmniBook XE2 Series	Green(19V)	C
COMPAQ	Presario 1692	Green(19V)	C	DELL	Latitude CPI 366XT	Red(18V)	F	FUJITSU	C Series C340	Blue(16V)	A	FUJITSU	Lifebook 280Dx	Blue(16V)	A	GATEWAY	Solo 2150 Series	Green(19V)	D	HEWLETT PACKARD	OmniBook XE3 Series	Green(19V)	C
COMPAQ	Presario 1693	Green(19V)	C	DELL	Latitude CPI A400XT	Red(18V)	F	FUJITSU	C Series C350	Blue(16V)	A	FUJITSU	Lifebook 400 Series	Blue(16V)	A	GATEWAY	Solo 2200 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion 5159	Green(19V)	C
COMPAQ	Presario 1694	Green(19V)	C	DELL	Latitude CPI Series	Red(18V)	F	FUJITSU	C Series C352	Blue(16V)	A	FUJITSU	Lifebook 420Dx	Blue(16V)	A	GATEWAY	Solo 2300 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3100 Series	Green(19V)	C
COMPAQ	Presario 1700 Series	Green(19V)	C	DELL	Latitude CPI300ST	Red(18V)	F	FUJITSU	C Series C360	Blue(16V)	A	FUJITSU	Lifebook 435Dx	Blue(16V)	A	GATEWAY	Solo 2500 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3110	Green(19V)	C
COMPAQ	Presario 1800 Series	Green(19V)	C	DELL	Latitude CPI300XT	Red(18V)	F	FUJITSU	C Series C4120	Blue(16V)	A	FUJITSU	Lifebook 500 Series	Blue(16V)	A	GATEWAY	Solo 2550 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3150	Green(19V)	C
COMPAQ	Presario 1800T Series	Green(19V)	C	DELL	Latitude CPI Series	Red(18V)	F	FUJITSU	C Series C4235	Blue(16V)	A	FUJITSU	Lifebook 531T	Blue(16V)	A	GATEWAY	Solo 3100 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3190	Green(19V)	C
COMPAQ	Presario 1810	Green(19V)	C	DELL	Latitude CPx H500GT	Red(18V)	F	FUJITSU	C Series C5130	Blue(16V)	A	FUJITSU	Lifebook 535T	Blue(16V)	A	GATEWAY	Solo 3150 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3200 Series	Green(19V)	C
COMPAQ	Presario 1825	Green(19V)	C	DELL	Latitude CPx Series	Red(18V)	F	FUJITSU	C Series C5235	Blue(16V)	A	FUJITSU	Lifebook 555Tx	Blue(16V)	A	GATEWAY	Solo 5100 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3210	Green(19V)	C
COMPAQ	Presario 1830	Green(19V)	C	DELL	Latitude CS/CSx Series	Red(18V)	F	FUJITSU	C Series C6320	Blue(16V)	A	FUJITSU	Lifebook 565Tx	Blue(16V)	A	GATEWAY	Solo 5150 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3215	Green(19V)	C
COMPAQ	Presario 300 Series	Red(18V)	E	DELL	Latitude LSH 400ST	Red(18V)	F	FUJITSU	C Series C6330	Blue(16V)	A	FUJITSU	Lifebook 585Tx	Blue(16V)	A	GATEWAY	Solo 5300 Series	Green(19V)	C	HEWLETT PACKARD	Pavilion N3220	Green(19V)	C
COMPAQ	Presario 305	Red(18V)	E	DELL	Latitude XP Series: 100cx	Red(18V)	A	FUJITSU	C Series C6525	Blue(16V)	A	FUJITSU	Lifebook 600 Series	Blue(16V)	A	GATEWAY	Solo 9100 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3250	Green(19V)	C
COMPAQ	Presario 800	Green(19V)	C	DELL	Latitude XP Series: 4100C	Red(18V)	A	FUJITSU	C Series C6535	Blue(16V)	A	FUJITSU	Lifebook 635T	Blue(16V)	A	GATEWAY	Solo 9300 Series	Green(19V)	C	HEWLETT PACKARD	Pavilion N3270	Green(19V)	C
COMPAQ	Prosignia 170	Red(18V)	E	DELL	Latitude XP Series: 4100D	Red(18V)	A	FUJITSU	C Series C6547	Blue(16V)	A	FUJITSU	Lifebook 635Tx	Blue(16V)	A	GATEWAY	Solo 9500	Green(19V)	D	HEWLETT PACKARD	Pavilion N3290	Green(19V)	C
COMPAQ	Prosignia 190	Red(18V)	E	DELL	Latitude XP Series: 4100T	Red(18V)	A	FUJITSU	C Series C6556	Blue(16V)	A	FUJITSU	Lifebook 655Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 2100 Series	Green(19V)	D	HEWLETT PACKARD	Pavilion N3295	Green(19V)	C
DELL	Inspiron 2000	Green(19V)	F	DELL	Latitude XP Series: 450c	Red(18V)	A	FUJITSU	C Series C6577	Blue(16V)	A	FUJITSU	Lifebook 656Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 2103	Green(19V)	C	HEWLETT PACKARD	Pavilion N3300 Series	Green(19V)	C
DELL	Inspiron 2500	Red(18V)	F	DELL	Latitude XP Series: 450x	Red(18V)	A	FUJITSU	C-Series 6535	Blue(16V)	A	FUJITSU	Lifebook 675Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 2105	Green(19V)	C	HEWLETT PACKARD	Pavilion N3310	Green(19V)	C
DELL	Inspiron 3000	Green(19V)	C	DELL	Latitude XP Series: 475c	Red(18V)	A	FUJITSU	E Series E330	Blue(16V)	A	FUJITSU	Lifebook 690Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 3000 Series	Green(19V)	C	HEWLETT PACKARD	Pavilion N3330	Green(19V)	C
DELL	Inspiron 3200	Green(19V)	C	DELL	Latitude XP Series: 475D	Red(18V)	A	FUJITSU	E Series E340	Blue(16V)	A	FUJITSU	Lifebook 700 Series	Blue(16V)	A	HEWLETT PACKARD	OmniBook 3100 Series	Green(19V)	C	HEWLETT PACKARD	Pavilion N3350	Green(19V)	C
DELL	Inspiron 3500	Green(19V)	C	DELL	Latitude XP Series: Xpi Series	Red(18V)	F	FUJITSU	E Series E342	Blue(16V)	A	FUJITSU	Lifebook 735Dx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 3101	Green(19V)	C	HEWLETT PACKARD	Pavilion N3370	Green(19V)	C
DELL	Inspiron 3700	Red(18V)	F	DFI	6600 Series	Green(19V)	C	FUJITSU	E Series E350	Blue(16V)	A	FUJITSU	Lifebook 755Tx	Blue(16V)	A	HEWLETT PACKARD	OmniBook 4100 Series	Green(19V)	C	HEWLETT PACKARD	Pavilion N3390	Green(19V)	C

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.
HEWLETT PACKARD	Pavillon N5000	Green(19V)	C	IBM	Thinkpad 290	Blue(16V)	C	IBM	Thinkpad 770X	Blue(16V)	C	SONY	Vaio FX770K	Green(19V)	A	SONY	VAIO PCG-F370	Green(19V)	A	SONY	VAIO PCG-FX170	Green(19V)	A
HEWLETT PACKARD	Pavillon N5100	Green(19V)	C	IBM	Thinkpad 310	Green(19V)	D	IBM	Thinkpad 770Z	Blue(16V)	C	SONY	Vaio FX800	Green(19V)	A	SONY	VAIO PCG-F390	Green(19V)	A	SONY	VAIO PCG-FX190	Green(19V)	A
HEWLETT PACKARD	Pavillon N5125	Green(19V)	C	IBM	Thinkpad 310D	Green(19V)	D	IBM	Thinkpad A20, A21	Blue(16V)	C	SONY	Vaio FX880K	Green(19V)	A	SONY	VAIO PCG-F400LT	Green(19V)	A	SONY	VAIO PCG-FX200	Green(19V)	A
HEWLETT PACKARD	Pavillon N5130	Green(19V)	C	IBM	Thinkpad 310E	Green(19V)	D	IBM	Thinkpad i1720	Blue(16V)	C	SONY	Vaio FXA32	Green(19V)	A	SONY	VAIO PCG-F403	Green(19V)	A	SONY	VAIO PCG-FX770K	Green(19V)	A
HEWLETT PACKARD	Pavillon N5159	Green(19V)	C	IBM	Thinkpad 310ED	Green(19V)	D	IBM	Thinkpad i1721	Blue(16V)	C	SONY	Vaio FXA33	Green(19V)	A	SONY	VAIO PCG-F409	Green(19V)	A	SONY	VAIO PCG-FX800	Green(19V)	A
HEWLETT PACKARD	Pavillon N5190	Green(19V)	C	IBM	Thinkpad 365	Blue(16V)	C	IBM	Thinkpad R-Series	Blue(16V)	C	SONY	Vaio FXA36	Green(19V)	A	SONY	VAIO PCG-F420	Green(19V)	A	SONY	VAIO PCG-FX880K	Green(19V)	A
HEWLETT PACKARD	Pavillon N5270	Green(19V)	C	IBM	Thinkpad 365XD	Blue(16V)	C	IBM	Thinkpad T20 2647, T21	Blue(16V)	C	SONY	VAIO PCG-700 Series	Green(19V)	A	SONY	VAIO PCG-F430	Green(19V)	A	SONY	VAIO PCG-GR100K	Blue(16V)	A
HEWLETT PACKARD	Pavillon N5271	Green(19V)	C	IBM	Thinkpad 380	Blue(16V)	C	IBM	Thinkpad T22	Blue(16V)	C	SONY	VAIO PCG-705	Green(19V)	A	SONY	VAIO PCG-F450	Green(19V)	A	SONY	VAIO PCG-GR170K	Blue(16V)	A
HEWLETT PACKARD	Pavillon N5350	Green(19V)	C	IBM	Thinkpad 380D	Blue(16V)	C	PANASONIC	CF48	Blue(16V)	A	SONY	VAIO PCG-707	Green(19V)	A	SONY	VAIO PCG-F480	Green(19V)	A	SONY	VAIO PCG-R505CT	Green(19V)	A
HEWLETT PACKARD	Pavillon XH156	Green(19V)	C	IBM	Thinkpad 380E	Blue(16V)	C	PANASONIC	CF01+	Blue(16V)	A	SONY	VAIO PCG-717	Green(19V)	A	SONY	VAIO PCG-F480K	Green(19V)	A	SONY	VAIO PCG-R505CTS	Green(19V)	A
IBM	Thinkpad "I" Series 1410i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 380ED	Blue(16V)	C	PANASONIC	CF17+	Blue(16V)	A	SONY	VAIO PCG-719	Green(19V)	A	SONY	VAIO PCG-F490K	Green(19V)	A	SONY	VAIO PCG-R505DT	Green(19V)	A
IBM	Thinkpad "I" Series 1411i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 380XD	Blue(16V)	C	PANASONIC	CF25+	Blue(16V)	A	SONY	VAIO PCG-729	Green(19V)	A	SONY	VAIO PCG-F520	Green(19V)	A	SONY	VAIO PCG-R505TE	Green(19V)	A
IBM	Thinkpad "I" Series 1412i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 380Z	Blue(16V)	C	PANASONIC	CF27+	Blue(16V)	A	SONY	VAIO PCG-731	Green(19V)	A	SONY	VAIO PCG-F540	Green(19V)	A	SONY	VAIO PCG-R505TEK	Green(19V)	A
IBM	Thinkpad "I" Series 1420i (2621-xxx)	Blue(16V)	C	IBM	Thinkpad 385	Blue(16V)	C	PANASONIC	CF33+	Blue(16V)	A	SONY	VAIO PCG-735	Green(19V)	A	SONY	VAIO PCG-F540K	Green(19V)	A	SONY	VAIO PCG-R505TS	Green(19V)	A
IBM	Thinkpad "I" Series 1434i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 385D	Blue(16V)	C	PANASONIC	CF34+	Blue(16V)	A	SONY	VAIO PCG-748	Green(19V)	A	SONY	VAIO PCG-F560	Green(19V)	A	SONY	VAIO PCG-SR11K	Blue(16V)	A
IBM	Thinkpad "I" Series 1435i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 385ED	Blue(16V)	C	PANASONIC	CF35+	Blue(16V)	A	SONY	VAIO PCG-800 Series	Green(19V)	A	SONY	VAIO PCG-F560K	Green(19V)	A	SONY	VAIO PCG-SR17	Blue(16V)	A
IBM	Thinkpad "I" Series 1436i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 385XD	Blue(16V)	C	PANASONIC	CF37+	Blue(16V)	A	SONY	VAIO PCG-808	Green(19V)	A	SONY	VAIO PCG-F580	Green(19V)	A	SONY	VAIO PCG-SR17K	Blue(16V)	A
IBM	Thinkpad "I" Series 1450i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 390	Blue(16V)	C	PANASONIC	CF45+	Blue(16V)	A	SONY	VAIO PCG-812	Green(19V)	A	SONY	VAIO PCG-F580K	Green(19V)	A	SONY	VAIO PCG-SR1K	Blue(16V)	A
IBM	Thinkpad "I" Series 1451i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 390E	Blue(16V)	C	PANASONIC	CF47+	Blue(16V)	A	SONY	VAIO PCG-818	Green(19V)	A	SONY	VAIO PCG-F590	Green(19V)	A	SONY	VAIO PCG-SR21K	Blue(16V)	A
IBM	Thinkpad "I" Series 1452i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 390X	Blue(16V)	C	PANASONIC	CF61+	Blue(16V)	A	SONY	VAIO PCG-838	Green(19V)	A	SONY	VAIO PCG-F590K	Green(19V)	A	SONY	VAIO PCG-SR5K	Blue(16V)	A
IBM	Thinkpad "I" Series 1460i (2621-xxx)	Blue(16V)	C	IBM	Thinkpad 560	Blue(16V)	C	PANASONIC	CF62+	Blue(16V)	A	SONY	VAIO PCG-C1X	Blue(16V)	A	SONY	VAIO PCG-F630	Green(19V)	A	SONY	VAIO PCG-SR7K	Blue(16V)	A
IBM	Thinkpad "I" Series 1470i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 560E	Blue(16V)	C	PANASONIC	CF71+	Blue(16V)	A	SONY	VAIO PCG-F150	Green(19V)	A	SONY	VAIO PCG-F660	Green(19V)	A	SONY	VAIO PCG-SR9G	Blue(16V)	A
IBM	Thinkpad "I" Series 1471i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 560X	Blue(16V)	C	PANASONIC	ToughBook 37	Blue(16V)	A	SONY	VAIO PCG-F160	Green(19V)	A	SONY	VAIO PCG-F670	Green(19V)	A	SONY	VAIO PCG-SR33	Blue(16V)	A
IBM	Thinkpad "I" Series 1472i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 560Z	Blue(16V)	C	PANASONIC	ToughBook CF72	Blue(16V)	A	SONY	VAIO PCG-F180	Green(19V)	A	SONY	VAIO PCG-F680	Green(19V)	A	SONY	VAIO PCG-XE17	Green(19V)	A
IBM	Thinkpad "I" Series 1480i (2621-xxx)	Blue(16V)	C	IBM	Thinkpad 570	Blue(16V)	C	SONY	Vaio FX103	Green(19V)	A	SONY	VAIO PCG-F190	Green(19V)	A	SONY	VAIO PCG-F690	Green(19V)	A	SONY	VAIO PCG-XE7	Green(19V)	A
IBM	Thinkpad "I" Series 1500i (2611-xxx)	Green(19V)	D	IBM	Thinkpad 600	Blue(16V)	C	SONY	Vaio FX105K	Green(19V)	A	SONY	VAIO PCG-F250	Green(19V)	A	SONY	VAIO PCG-F707	Green(19V)	A	SONY	VAIO PCG-XG Series	Green(19V)	A
IBM	Thinkpad "I" Series 1500i (2621-xxx)	Blue(16V)	C	IBM	Thinkpad 600E	Blue(16V)	C	SONY	Vaio FX109K	Green(19V)	A	SONY	VAIO PCG-F270	Green(19V)	A	SONY	VAIO PCG-F801A	Green(19V)	A	SONY	VAIO PCG-XG18	Green(19V)	A
IBM	Thinkpad "A" Series	Green(19V)	D	IBM	Thinkpad 600X	Blue(16V)	C	SONY	Vaio FX120	Green(19V)	A	SONY	VAIO PCG-F280	Green(19V)	A	SONY	VAIO PCG-F807	Green(19V)	A	SONY	VAIO PCG-XG19	Green(19V)	A
IBM	Thinkpad "X" Series X20, X21, X22	Blue(16V)	C	IBM	Thinkpad 701	Blue(16V)	C	SONY	Vaio FX170	Green(19V)	A	SONY	VAIO PCG-F290	Green(19V)	A	SONY	VAIO PCG-FX103	Green(19V)	A	SONY	VAIO PCG-XG28	Green(19V)	A
IBM	Thinkpad 1200i	Blue(16V)	C	IBM	Thinkpad 770	Blue(16V)	C	SONY	Vaio FX190	Green(19V)	A	SONY	VAIO PCG-F340	Green(19V)	A	SONY	VAIO PCG-FX105K	Green(19V)	A	SONY	VAIO PCG-XG28K	Green(19V)	A
IBM	Thinkpad 240	Blue(16V)	C	IBM	Thinkpad 770E	Blue(16V)	C	SONY	Vaio FX200	Green(19V)	A	SONY	VAIO PCG-F350	Green(19V)	A	SONY	VAIO PCG-FX109K	Green(19V)	A	SONY	VAIO PCG-XG29	Green(19V)	A
IBM	Thinkpad 240X	Blue(16V)	C	IBM	Thinkpad 770ED	Blue(16V)	C	SONY	Vaio FX270	Green(19V)	A	SONY	VAIO PCG-F360	Green(19V)	A	SONY	VAIO PCG-FX120	Green(19V)	A	SONY	VAIO PCG-XG38	Green(19V)	A

## Compatible Notebook Computers Model List

The Setup Procedures of the power adapter could be founded in the User Manual. From this page, you could easily find what "Tip" and "Voltage Selection Device" is suitable for your Notebook Computer model.

Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.	Brand Name	Model Number	Voltage Device	Tip No.
SONY	VAIO PCG-XG39	Green(19V)	A	TOSHIBA	T4850	Red(18V)	D	TOSHIBA	Satellite 1715 XCDS	Green(19V)	C	TOSHIBA	Satellite 2675	Purple(15V)	B	TOSHIBA	Satellite 5100 Series, 5105	Purple(15V)	B	TOSHIBA	Tecra 8200	Purple(15V)	B
SONY	VAIO PCG-XG39K	Green(19V)	A	TOSHIBA	T4900	Red(18V)	D	TOSHIBA	Satellite 1730 Series	Green(19V)	C	TOSHIBA	Satellite 2715	Purple(15V)	B	TOSHIBA	Satellite 5200, 5205 Series	Purple(15V)	B	TOSHIBA	Tecra 9000	Purple(15V)	B
SONY	VAIO PCG-XG9	Green(19V)	A	TOSHIBA	Libretto 50	Purple(15V)	B	TOSHIBA	Satellite 1735 Series	Green(19V)	C	TOSHIBA	Satellite 2755	Purple(15V)	B	TOSHIBA	Satellite Pro 4220 Series	Purple(15V)	B	TOSHIBA	Tecra 9100	Purple(15V)	B
SONY	VAIO PCG-Z505	Green(19V)	A	TOSHIBA	Libretto 70	Purple(15V)	B	TOSHIBA	Satellite 1750 Series	Green(19V)	C	TOSHIBA	Satellite 2775	Purple(15V)	B	TOSHIBA	Satellite Pro 4260	Purple(15V)	B	TWINHEAD	P88T	Green(19V)	C
SONY	VAIO PCG-Z505FA	Green(19V)	A	TOSHIBA	Portege 2000	Purple(15V)	B	TOSHIBA	Satellite 1755 Series	Green(19V)	C	TOSHIBA	Satellite 2800 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 4280	Purple(15V)	B	WINBOOK	Winbook FX	Green(19V)	D
SONY	VAIO PCG-Z505GA	Green(19V)	A	TOSHIBA	Portege 300	Purple(15V)	B	TOSHIBA	Satellite 1800	Purple(15V)	B	TOSHIBA	Satellite 2800T	Purple(15V)	B	TOSHIBA	Satellite Pro 4300 Series	Purple(15V)	B	WINBOOK	Winbook J1	Green(19V)	C
SONY	VAIO PCG-Z505GAH	Green(19V)	A	TOSHIBA	Portege 3500/3505 Series	Purple(15V)	B	TOSHIBA	Satellite 1805	Purple(15V)	B	TOSHIBA	Satellite 2805 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 440 Series	Purple(15V)	B	WINBOOK	Winbook Si	Green(19V)	C
SONY	VAIO PCG-Z505GAM	Green(19V)	A	TOSHIBA	Portege 4010 Series	Purple(15V)	B	TOSHIBA	Satellite 2060	Purple(15V)	B	TOSHIBA	Satellite 3000	Green(19V)	C	TOSHIBA	Satellite Pro 445 Series	Purple(15V)	B	WINBOOK	Winbook Si2	Green(19V)	C
SONY	VAIO PCG-Z505HE	Green(19V)	A	TOSHIBA	Portege 320	Purple(15V)	B	TOSHIBA	Satellite 2065	Purple(15V)	B	TOSHIBA	Satellite 3005	Green(19V)	C	TOSHIBA	Satellite Pro 460 Series	Purple(15V)	B	WINBOOK	Winbook X1	Green(19V)	C
SONY	VAIO PCG-Z505HS	Green(19V)	A	TOSHIBA	Portege 610	Purple(15V)	B	TOSHIBA	Satellite 2095	Purple(15V)	B	TOSHIBA	Satellite 305 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 4600 Series	Purple(15V)	B	WINBOOK	Winbook X11	Green(19V)	E
SONY	VAIO PCG-Z505HSK	Green(19V)	A	TOSHIBA	Portege 620	Purple(15V)	B	TOSHIBA	Satellite 2100	Purple(15V)	B	TOSHIBA	Satellite 315 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 465 Series	Purple(15V)	B	WINBOOK	Winbook XL	Green(19V)	E
SONY	VAIO PCG-Z505JE	Green(19V)	A	TOSHIBA	Portege 650	Purple(15V)	B	TOSHIBA	Satellite 2105	Purple(15V)	B	TOSHIBA	Satellite 320 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 470 Series	Purple(15V)	B	WINBOOK	Winbook XL2	Green(19V)	E
SONY	VAIO PCG-Z505JEK	Green(19V)	A	TOSHIBA	Portege 660	Purple(15V)	B	TOSHIBA	Satellite 210CS	Purple(15V)	B	TOSHIBA	Satellite 325 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 480 Series	Purple(15V)	B	WINBOOK	Winbook XL3	Green(19V)	E
SONY	VAIO PCG-Z505JS	Green(19V)	A	TOSHIBA	Portege 7000	Purple(15V)	B	TOSHIBA	Satellite 2140	Purple(15V)	B	TOSHIBA	Satellite 330 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 490 Series	Purple(15V)	B	WINBOOK	Winbook XP	Green(19V)	C
SONY	VAIO PCG-Z505JSK	Green(19V)	A	TOSHIBA	Portege 7010	Purple(15V)	B	TOSHIBA	Satellite 2180	Purple(15V)	B	TOSHIBA	Satellite 335 Series	Purple(15V)	B	TOSHIBA	Satellite Pro 490X	Purple(15V)	B	WINBOOK	Winbook XP5	Green(19V)	C
SONY	VAIO PCG-Z505LE	Green(19V)	A	TOSHIBA	Portege 7020	Purple(15V)	B	TOSHIBA	Satellite 220 Series	Purple(15V)	B	TOSHIBA	Satellite 4000	Purple(15V)	B	TOSHIBA	Satellite Pro 6000 Series	Purple(15V)	B	WINBOOK	Winbook XP5Pro	Green(19V)	D
SONY	VAIO PCG-Z505LEK	Green(19V)	A	TOSHIBA	Portege 7030	Purple(15V)	B	TOSHIBA	Satellite 2210	Purple(15V)	B	TOSHIBA	Satellite 4005	Purple(15V)	B	TOSHIBA	Tecra 510CDT	Purple(15V)	B	WINBOOK	Winbook Z1	Green(19V)	C
SONY	VAIO PCG-Z505LS	Green(19V)	A	TOSHIBA	Portege 7140	Purple(15V)	B	TOSHIBA	Satellite 225 Series	Purple(15V)	B	TOSHIBA	Satellite 4010	Purple(15V)	B	TOSHIBA	Tecra 520	Purple(15V)	B				
SONY	VAIO PCG-Z505LSK	Green(19V)	A	TOSHIBA	Portege 7200	Purple(15V)	B	TOSHIBA	Satellite 2250	Purple(15V)	B	TOSHIBA	Satellite 4015	Purple(15V)	B	TOSHIBA	Tecra 520CDS/CDT	Purple(15V)	B				
SONY	VAIO PCG-Z505R	Green(19V)	A	TOSHIBA	Portege 7220	Purple(15V)	B	TOSHIBA	Satellite 230CX	Purple(15V)	B	TOSHIBA	Satellite 4020	Purple(15V)	B	TOSHIBA	Tecra 530	Purple(15V)	B				
SONY	VAIO PCG-Z505RX	Green(19V)	A	TOSHIBA	Portege 7220Cte	Purple(15V)	B	TOSHIBA	Satellite 2410 Series	Purple(15V)	B	TOSHIBA	Satellite 4025	Purple(15V)	B	TOSHIBA	Tecra 550	Purple(15V)	B				
SONY	VAIO PCG-Z505S	Green(19V)	A	TOSHIBA	Satellite 1000	Green(19V)	C	TOSHIBA	Satellite 2505	Purple(15V)	B	TOSHIBA	Satellite 4030	Purple(15V)	B	TOSHIBA	Tecra 700	Purple(15V)	B				
SONY	VAIO PCG-Z505SX	Green(19V)	A	TOSHIBA	Satellite 1005	Green(19V)	C	TOSHIBA	Satellite 2515	Purple(15V)	B	TOSHIBA	Satellite 4060	Purple(15V)	B	TOSHIBA	Tecra 710	Purple(15V)	B				
SONY	VAIO PictureBook PCG-C1X	Blue(16V)	A	TOSHIBA	Satellite 1100/1100	Green(19V)	C	TOSHIBA	Satellite 2520 Series	Purple(15V)	B	TOSHIBA	Satellite 4070	Purple(15V)	B	TOSHIBA	Tecra 720	Purple(15V)	B				
TOSHIBA	T1900	Red(18V)	D	TOSHIBA	Satellite 1200 Series	Green(19V)	C	TOSHIBA	Satellite 2525 Series	Purple(15V)	B	TOSHIBA	Satellite 4080	Purple(15V)	B	TOSHIBA	Tecra 720CDT	Purple(15V)	B				
TOSHIBA	T1900/CS	Red(18V)	D	TOSHIBA	Satellite 1410/1415	Purple(15V)	B	TOSHIBA	Satellite 2540	Purple(15V)	B	TOSHIBA	Satellite 4090	Purple(15V)	B	TOSHIBA	Tecra 730	Purple(15V)	B				
TOSHIBA	T200	Purple(15V)	B	TOSHIBA	Satellite 1555	Purple(15V)	B	TOSHIBA	Satellite 2545	Purple(15V)	B	TOSHIBA	Satellite 4100	Purple(15V)	B	TOSHIBA	Tecra 730CDT/XX/CDT	Purple(15V)	B				
TOSHIBA	T2400	Red(18V)	D	TOSHIBA	Satellite 1605	Green(19V)	C	TOSHIBA	Satellite 2590	Purple(15V)	B	TOSHIBA	Satellite 4320	Purple(15V)	B	TOSHIBA	Tecra 740	Purple(15V)	B				
TOSHIBA	T4500	Red(18V)	D	TOSHIBA	Satellite 1615	Purple(15V)	B	TOSHIBA	Satellite 2595	Purple(15V)	B	TOSHIBA	Satellite 4340	Purple(15V)	B	TOSHIBA	Tecra 750	Purple(15V)	B				
TOSHIBA	T4600	Red(18V)	D	TOSHIBA	Satellite 1625	Green(19V)	C	TOSHIBA	Satellite 2610	Purple(15V)	B	TOSHIBA	Satellite 4360	Purple(15V)	B	TOSHIBA	Tecra 780	Purple(15V)	B				
TOSHIBA	T4700	Red(18V)	D	TOSHIBA	Satellite 1675	Green(19V)	C	TOSHIBA	Satellite 2615	Purple(15V)	B	TOSHIBA	Satellite 4600 Series	Purple(15V)	B	TOSHIBA	Tecra 8000	Purple(15V)	B				
TOSHIBA	T4800	Red(18V)	D	TOSHIBA	Satellite 1695	Green(19V)	C	TOSHIBA	Satellite 2655	Purple(15V)	B	TOSHIBA	Satellite 5005 Series	Purple(15V)	B	TOSHIBA	Tecra 8100 Series	Purple(15V)	B				